Instructions Drain Cover With Handles

This cover is used as a temporary solution to seal and protect drains from accidental spills of oils, chemicals or unwanted liquids.



Step 1.Prepare surface around the drain, making sure it's free of debris.



Step 3. Place the cover over the drain with the polyurethane side down, pressing firmly to reinforce adhesion.



Step 5. When the cover is completely clean of dirt, debris and spill residue, be sure the polyurethane side is up and roll the cover onto its silicone fabric.



Step 2. Hold the cover by the handles and unroll it.



Step 4. When job is done, pull up the cover and clean it with soap and warm water, a nonabrasive detergent, or petroleum solvent cleaner.



Step 6.Store in bag until next use.

Urethane Notice: Due to the nature of softer urethane, the physical properties of these products may change over time with exposure to certain environmental conditions like temperature, humidity, and UV radiation. Please inspect the stored product regularly to ensure it is in a usable state. For more details and for chemical compatibility, please contact your local distributor. For optimum performance, ensure that the area surrounding your drain is free of debris, cracks and holes.