

PIG HazMat Absorbents

Before you attempt hazardous spill cleanup, take these precautions:

- Always put safety first. If spilled material is unknown, assume the worst.
- Assess the spill and select proper personal protective equipment.
- If possible, stop the source of the spill.

Follow these easy steps to assure maximum effectiveness:

1. Contain the spill

Contain the spill by surrounding it with PIG HazMat Absorbent Socks and Dikes.

2. Absorb the contained spill

Absorb the contained spill with PIG HazMat Pillows for large-volume spills and PIG HazMat Pads, Rolls and Pulp for smaller-volume spills.

3. Dispose of used absorbents

Dispose of used absorbents in compliance with local and country regulations.

NOTICE: To ensure effectiveness and your safety, we recommend that you conduct compatibility and absorption testing of your chemicals with PIG HazMat products prior to purchase. If you have any questions or need samples to test, please call Technical Services.

WARNING: Liquids absorbed by product(s) supplied by New Pig will not be rendered less hazardous, less toxic, or less flammable. Liquids absorbed will remain in their original state after absorption occurs.

PLEASE NOTE: PIG Absorbent products must be disposed of in compliance with local and country regulations. This product is considered non-hazardous in its purchased or unused state and requires no special procedures. Used absorbents take on the properties of the liquids absorbed and must be disposed of in accordance with pertinent local and country regulations.

