PIG Above-the-Ceiling Leak Diverter

Instructions

Please read through all instructions before assembling the diverter.

Tools Needed: Pliers

Unpack and remove vinyl leak diverter with tubular frame supports from the box. Set the two small frame supports on either side of the diverter.



1. Fully open the diverter and lay flat on a sturdy surface with support legs pointing up. 2. Slide the small support frame through the end pocket. Grasp the corner and insert the end of



 Slide the small support frame through the end pocket. Grasp the corner and insert the end of the support tube into the "Y" connector and snug into place. Repeat on opposite corner. Follow same steps for the other side of diverter.



 Locate enclosed barbed fitting and 2 hose clamps. Slide one clamp onto the hose and the other clamp onto drain valve that is attached to the diverter. Push the barbed fitting into end of hose and drain valve until secured into place.



 Slide clamps over the barbed fitting and pinch together with pliers to secure the clamp onto the hose and fitting.



5. Flip assembled diverter over with legs down on flat surface and adjust until unit is level.



6. Position diverter on top of suspended ceiling under the leak. Run the hose to a drain or collection container.

NOTES:

- Hose needs to be lower than diverter for proper draining. An optional tie strap has been provided to secure hose to a stationary object.
- Check Leak Diverter periodically for debris that can cause clogging.
- Leak Diverter is not suitable for temperatures over 170°F / 77°C.