# PIG Build-A-Berm Barrier

## **Instructions**

## Step 1. Prepare Floor.

The surface must be free of debris. Any buildup of grease and oil must be removed. An improperly prepared surface may cause premature failure of the sealant for Build-A-Berm Barrier.

## Step 2. Fill any cracks.

To apply a Build-A-Berm Barrier over frost cracks and form separations, first fill these areas with sealant or caulking.

## Step 3. Apply sealant.

Apply two continuous beads of sealant (not included) on the bottom of the Build-A-Berm Barrier approximately 2-3cm in from each side and ends, along its entire length.

## Step 4. Build your barrier.

Place Build-A-Berm Barrier and apply pressure to its entire length to seal it to the floor.

**NOTE:** To ensure proper sealing on uneven surfaces, you may need to apply extra sealant and more direct pressure.

#### **Step 5. Customise your layout.**

To add sections or attach corners to the Build-A-Berm Barrier, apply vinyl glue or sealant (not included) to the built-in vinyl cover and the end of the berm. Then mold the vinyl cover over the berm end and hold it in place approximately 30 seconds.

## **IMPORTANT NOTES:**

- 1. If it has been stored coiled, let the Build-A-Berm Barrier relax and lie flat for two hours before installing it.
- 2. In cooler climates (below 70°F/21°C) allow Build-A-Berm Barrier to relax and lie flat for longer.
- 3. For better adhesion, scuff the bottom of the Build-A-Berm Barrier with sandpaper.
- 4. Let the Build-A-Berm Barrier cure (sealant and glue) for at least one hour before use.
- 5. To cut Build-A-Berm Barrier, use a utility knife along with a straight edge.
- 6. To remove Build-A-Berm Barrier, scrape with a flat-blade shovel and use silicone remover to clean sealant from base.





Last revised 18/10/19 359305