



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: BOM406
Item Name	: PIG® Oil-Only Booms
Liquids Absorbed	: Oil-Only
Contents/Package	: 8 booms/bag
Colour	: White
Dimensions	: 8 cm Dia x 3 m
Composition	: Outer Mesh Skin - Polyester Inner Skin - Polypropylene Pulp Filler - Polypropylene Clip/Ring - Zinc Plated Carbon Steel
Absorbency	: 60 L/Bag
Weight	: 10.9 Kg

Description

- Floats to confine and soak up spills on water; hugs ground for land-based spills
- Tough outer mesh is UV resistant for long-term outdoor use without degradation; lets fluids easily pass through to filler material
- Rope running along length of boom withstands up to 182kg loads, adding strength for deployment and retrieval
- Spunbond polypropylene skin is UV resistant up to 12 months; meets ANSI and MIL spec standards for static decay
- Booms float at surface for easy retrieval, even when saturated

Warnings & Restrictions	: When sea-weather condition is wind speed >5 knots & a (perpendicular) water-current speed >2 knots, this can cause oil absorbent booms to submerge, allowing oil to pass over them. Waves higher than freeboard (above water) portion of boom will push oil over absorbent booms; optimal sea-weather condition for usage is typically Beaufort Scale #2 or less.
------------------------------------	---

Recycled Content	: 98% Pre-Consumer Recycled Polypropylene Filler
-------------------------	--