



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: ORFH150
Item Name	: PIG® Essentials Pro Oil-Only Mat Roll
Liquids Absorbed	: Oil-Only
Contents/Package	: 1 roll/package
Colour	: White
Dimensions	: 45.7 m x 76 cm
Composition	: 100% Polypropylene
Absorbency	: 189 L/Package
Weight	: 11.6 Kg

Description

- Random assembly of large-diameter MeltBlown poly fibres creates a lofty inner layer that absorbs high volumes of oil — but not water — fast
- Low-profile sorbent can be used wherever you need to catch oil leaks, spills or overspray; HeavyWeight construction offers the greatest sorbency
- Top and bottom layers of FineFiber are built of densely-woven, small-diameter strands of fibre to increase surface area, enabling the mat to grip surfaces securely
- Sonic-bonded "Dimples" add fast-wicking power and strength
- 3-ply construction gives Mat durability to resist heavy foot traffic for longer wear and fewer changeouts
- Perforated every 48 cm lengthwise and 38 cm widthwise