



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: OB20X6
Item Name	: PIG® Essentials Oil-Only Boom
Liquids Absorbed	: Oil-Only
Contents/Package	: 2 booms/package
Colour	: White
Dimensions	: 20 cm x 610 cm
Composition	: Polypropylene Filler/Polyester Netting/Plated-Steel Hardware
Absorbency	: 144 L/Package
Weight	: 14.5 Kg

Description

- Strong mesh outer sleeve encases a poly sock skin filled with highly-sorbent polypropylene; filler won't shed and Booms won't sink, even when saturated with oil
- Polypropylene filler is left in its natural hydrophobic state — repels water (and floats) while only absorbing oils and other hydrocarbons
- A nylon rope and sturdy hardware ensure long-lasting durability and easy retrieval
- Durable, easy-to-use connectors provide a simple and efficient way to link Sock/Net Booms together and create a containment system big enough to handle almost any size spill on water
- White colour makes it easy to see when it's fully saturated — you save money by not throwing it away too soon

Warnings & Restrictions	: When sea-weather condition is wind speed >5 knots & a (perpendicular) water-current speed >2 knots, this can cause oil absorbent booms to submerge, allowing oil to pass over them. Waves higher than freeboard (above water) portion of boom will push oil over absorbent booms; optimal sea-weather condition for usage is typically Beaufort Scale #2 or less.
------------------------------------	---

Recycled Content	: 100% Post-Industrial Recycled Polypropylene Filler
-------------------------	--