



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: MRFH150
Item Name	: PIG® Essentials Pro Universal Mat Roll
Liquids Absorbed	: Oil, Coolants, Solvents & Water
Contents/Package	: 1 roll/package
Colour	: Grey
Dimensions	: 45.7 m x 76 cm
Composition	: 100% Polypropylene
Absorbency	: 189 L/Package
Weight	: 11.6 Kg

Description

- Top and bottom layers of FineFibre are built of densely-woven, small-diameter strands of fibre to increase surface area — enabling the Mat to grip the floor and secure it for safer walking
- Large-diameter MeltBlown polypropylene fibres create a high-loft inner layer that absorbs high volumes of liquid fast
- HeavyWeight construction offers the greatest sorbency
- Sonic-bonded "Dimples" add fast-wicking power and strength
- 3-ply construction gives Mat durability to resist heavy foot traffic for longer wear and fewer changeouts
- Perforated every 48 cm lengthwise and 38 cm widthwise