



Tel: +31 (0)76 596 9250
Email: pigpost@newpig.com

PRODUCT DATA SHEET

Item Number	: PLR267
Item Name	: PIG® SpillBlocker® Dike
Contents/Package	: 2/box
Colour	: Yellow or Black
Dimensions	: 9cm W x 152cm L x 7.6cm H
Composition	: 100% polyurethane
Weight	: 11.3 Kg

Description

- Exclusive New Pig formulation features a tear-resistant top layer and a flexible, tacky bottom layer that seals tight to smooth surfaces and blocks liquids
- Fast protection for when a spill is heading right for your drain; just place dike in front of spill to contain liquid
- Built-in dovetail connectors create a liquid-proof seal and allow you to join as many sections as you need without extra parts
- 7.6cm height is great for containing deeper pools of liquid and larger flows
- Reusable dikes clean easily with soap and water

Warnings & Restrictions	: Due to the nature of softer urethane, the physical properties of these products may change over time with exposure to certain environmental conditions like temperature, humidity and UV radiation. Typical life expectancy is 5 years. Please inspect the stored product regularly to ensure it is in a usable state. For more details and for chemical compatibility, please call Technical Services.
------------------------------------	---