



**Tel:** +31 (0)76 596 9250  
**Email:** pigpost@newpig.com

# PRODUCT DATA SHEET

<b>Item Number</b>	: FLTE700
<b>Item Name</b>	: Plant Nappy®
<b>Contents/Package</b>	: 1 each
<b>Colour</b>	: Yellow
<b>Dimensions</b>	: 68.5 cm L x 50 cm W x 8 cm H
<b>Composition</b>	: Cover: Vinyl Coated PVC Mesh; Base: Woven Olefin Fabric; Fill: Polypropylene & Polyester
<b>Absorbency</b>	: 2 L
<b>Weight</b>	: 0.95 Kg

## Description

- Ideal for outdoor use in wet and rainy conditions
- Contain spills on construction sites or where machinery needs to be left outside
- Non-permeable base fabric is laminated with an oil soak filter, and protected by a permeable top fabric to allow free passage of contaminants
- Permeable side wall contains filter fabric that allows free passage of water but not oil
- UV-resistant design stands up to harsh weather conditions
- Easy and cost-effective way to ensure environmentally friendly practice on site, avoiding possible prosecution or monetary fine for contamination of ground and water

**Warnings & Restrictions** : Temperature Limit(s): -20°C to 107°C